


## Neoline Dome LL-N300-30


**Wiring Diagram** Maximum run length with a power feed from one end is 15m.



### Installation

<p><b>1</b> When installing the neon, install evenly from both ends. Avoid installing in one direction.</p>	<p>If the length of neon is over 2m, it is recommended that the installation is carried out by two people.</p>
<p><b>2</b> To uninstall the neon, use a tool to carefully lever. Do not pull the neon forcefully or directly.</p>	

### Clip Installation



### Cutting

Neoline is made to order - modifications on site will void the Warranty.

### Bending

